



# Using your Heating and Hot Water System

(Update 8/20/04)

There are no valves concerning the heat or hot water systems that need to be changed for proper operation of this heating and hot water system (winter or summer).


Please **DO NOT** change the positions/settings of any valve or switch except for what is shown below.

The first two pictures below show the main water valve for your unit (a yellow levered ball valve) in the on and off position. You should **always** shut the water off to the unit when leaving after your stay.



The "water heater" is an "indirect" water heater and not an electric or propane water heater. The boilers (located on the end of the building) heat the water in the tank by passing hot water through the coils in this tank. The picture below shows the toggle switch on top of the tank.

**Make sure this toggle switch is in the on position to heat the water. Put the toggle switch in the off position when leaving the unit after your stay.**



If you believe you are having problems:

Please remember that the heating and hot water system is an Association expense. If you feel you have a problem with your heat or hot water **do not** call a plumber or the propane supplier directly as the Association will **not** cover the expense.

**If you are renting** call your rental agent **first** with any questions or problems you may have.

## OWNERS:

**Always call the TPW Management office at 464-5749 and they will take care of any problem you may have.**